



Thank you for purchasing this replacement ReplayTV upgrade drive. We've done everything possible to check and test this drive. All you have to do now is to swap the drive in your ReplayTV box with this one.

**WARNING:** Make sure your ReplayTV box is **UNPLUGGED** before you perform this procedure. Even though it is turned off, the box is constantly powered.

**WARNING:** Make sure you discharge yourself of static electricity before you perform the swap. You can do this by touching the metal part of the chassis periodically.

Remove the chassis cover by removing the 3 black screws from the back and 4 black screws from the bottom. Carefully slide the cover away from the bottom.

Carefully disconnect the IDE cable and power cable from your current hard drive.

Remove the drive by removing the screws around the drive cage.

Put the new drive into place and replace the screws. Reconnect the power and IDE cables.

Replace the chassis cover and the 7 screws.

Plug the power back into the unit. The unit will temporarily power up as it reloads the software. It will power down again.

Turn the unit back on and you should see the Welcome ReplayTV screen on your TV.

Run the ReplayTV setup to update Channel and Dialing Options as well as the Remote Control Codes.

After all of the above is complete, your ReplayTV box is ready for your use.

Store your original drive for safekeeping. It will be useful should this drive fail.

If you have any problems, please contact me via e-mail at [noel@replaytivo.us](mailto:noel@replaytivo.us) or phone at 609-577-5527